Contents

- <u>1 Controlling Devices and Groups</u>
 - 1.1 "Direct Level (Device/Group)" Setting up and Requesting the Status
 - 1.1.1 Setting up Values by Button
 - 1.1.2 Setting up Values by Level, Trigger Button and Up/Down Buttons
 - <u>1.2 "Recall Scene (Device/Group)" Recalling Scenes</u>
 - <u>1.3 "Direct Proportion (Device/Group)" Setting up Proportions</u>
 - 1.4 "Modify Proportion (Device/Group)" Modifying Proportions
- <u>2 Requests and Emergency Tests</u>
 - 2.1 "Query Load Level" Requests about the Device State
 - 2.2 "Query Device State" Requesting Device Parameters (Flags)

This section presents examples of commands to devices in the Helvar system. The commands can be activated with the help of various control items. Ways of receiving data about the equipment state are also presented here.

Controlling Devices and Groups

Commands for controlling devices and groups of devices in the Helvar system:

Command to Device:

Direct Level (Device) Recall Scene (Device) Direct Proportion (Device) Modify Proportion (Device) **Command to Group:** Direct Level (Group) Recall Scene (Group) Direct Proportion (Group) Modify Proportion (Group)

Description:

Setting up the status Recalling scenes Setting up proportions Modifying proportions

<u>↑ Back</u>

"Direct Level (Device/Group)" - Setting up and Requesting the Status

In order to send values to a device or a group of devices in the Helvar system, for example, to lock/unlock relays, set up the dimmer brightness and display the actual status in the project "Direct Level Device" and "Query Load Level" commands are used. They have to be set up in a particular way.

- **Direct Level (Device/Group)** the command of setting up the status. It send the value the device or group of devices should take
- **Query Load Level** the feedback channel requests the status of the controlled device and sends it to the interface with a particular frequency (for separate devices only).

Thus the set for controlling devices in the Helvar system consists of the command of setting up the value and the feedback channel for monitoring the device status:

PROJECT DEVICE PANEL		PROJECT DEVICE PANEL		
🕀 - 🗗 😫 🛧 🕂	🚥 👱 🍣	🕀 - 🗗 🙁 🛧 🕂	🚥 👱 🍣	
 System Tokens Project Tokens Drivers Helvar Net (TO Driver Tokens Commands Commands Feedback Dimmer 	P)	 System Tokens Project Tokens Drivers Helvar Net (TCP) Driver Tokens Commands Gommands Feedback Methods Feedback Dimmer 		
PROPERTIES		PROPERTIES		
Name	Dimmer	Name	Dimmer	
Command	Direct Level Device	Command	Query Load Level	
Cluster	1	Cluster	1	
Router	1	Router	1	
Subnet	1	Subnet	1	
Device	10	Device	10	
Fade Time	0	Use Timer	yes	
		Timer	1000	

Commands - commands to devices and groups of devices

- **Command: Direct Level (Device/Group)** setting up the status (switching the relay, controlling brightness)
- Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255) the device address (@ address) or Group (1..16383) the address of the group of devices in the Helvar system
- Fade Time (MC) (0..6553.5s) speed of changing the status from the current to the preset one after receiving the command of setting up the status

The status value for setting up is selected in "Value" when dragging commands to graphic items.

 $\ensuremath{\textbf{Feedbacks}}$ – feedback channels for displaying the status of devices

- Command: Query Load Level requesting and displaying the device status
- Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255) the device address (@ address) or Group (1..16383) the address of the group of devices in the Helvar system
- **Use Timer:** Yes requesting the device status by timer (HelvarNet does not send the status without the request). If the timer is off, the device status will not be received.
- **Timer, ms:** XXXX frequency of sending requests about the device status (in ms) how often information about the device state should be updated in the project. The less often is the update, the less load there is on the system.

Graphic items for setting up values (status):

When commands and feedback channels are set up it is required to assign them to graphic items. You can use the following types of graphic items:

- **Level** for regulating the brightness value in the preset range by moving the Level slider. It can be used for controlling one device or a group of devices.
- **Button** for sending a particular value. It stores and sends the selected value to the address of the controlled device. It can be used for controlling one device or a group of devices.
- **Trigger Button** for switching two preset brightness values, for example, 100% and 0% for brightness or 0/1 for relays. The values are indicated in the process of setting up the graphic item. The value for sending at the next pressing on the item is defined depending on the current value received via the feedback channel. That is why the item is used for controlling separate devices.
- **Up/Down Button** for incrementing or decrementing the dimmer value in relation to the current one which is received via the feedback channel. That is why the item is used for controlling separate devices.

<u>↑ Back</u>

Setting up Values by Button

Create <u>Button</u> with 1 or 2 states. With the help of Button you can send any value in the system after defining the available value range depending on the device type – relays (0-1), dimmers (0-100).

Drag the command from the device tree to Button. Select the **Send Number** tag in the dialog window:



Select the interface event and the value for sending:

- **Press** the command will be sent when pressing on the item.
- Release the command will be sent when releasing the item.

 \Rightarrow Values sent by Button should be in the available range. In the Helvar system the range for any device is 0 ~ 100, but the dimmer processes all values and the relay reacts to zero and non-zero value. At that there is no such thing as *operating limit* and if you will send the value which is less than this limit they relay does not work! The settings are formed when configuring Helvar.

Ways of reacting on events:

Button can work without the feedback channel (when controlling a group or when you don't need the device status in the project). Such Button will change its state to the second (active) one on pressing and will return to the initial state when releasing it. In order to do that indicate **Feedback: Momentary** in Object Properties: General - react on pressings.

Button can also work with feedback channel. Then it will change its state to the active one if the feedback channel sends any non-zero value. In this case we indicate **Feedback: Channel** in Object Properties: General – react on the device status. The feedback channel is assigned to Button with the **"In Value**" tag – react on the item state.

The assigned command and the feedback channel will be displayed in the **Programming** tab of the **Object Properties** window. If it is necessary the command can be transferred from the Press event to Release by dragging it by the text field.

<u>↑ Back</u>

Setting up Values by Level, Trigger Button and Up/Down Buttons

Level, Trigger Button, Up/Down Buttons are the graphic item types used for switching several values of the device status. They are set up differently but on the stage of assigning Helvar commands to them they function similarly. That is why they are presented in one section.

Level

Create a graphic item in Editor Workspace. Select **Type: Level** in Object Properties: General and indicate the item properties:

OBJECT PROPERTI	ES		0 50 100 150
General Pr	ogramming	States	0_ -
Name	Item 6		Dimmer 1
Left	191		50
Тор	83		· · · · · ·
Width	66		
Height	216		100
Active	True		-
Visible	True		
Specific			150
Туре	Level		150_
Feedback	Channel		
Hit	Active		
Min	0		200_
Max	100		
Direction	Vertical		
Range Type	Integer		250_
Focus Lock Receive	True		
Invert	False		· · · · · · · · ·
Slider	None		300_

In the settings of <u>Level</u> indicate:

- Feedback way of reacting on events:
 Channel for Level which will monitor the actual variable status,
 Momentary for Level which will NOT display the actual status of the controlled device
- Min: 0 the lowest value of the Level scale
- Max: 100 the lowest value of the Level scale

The Min...Max range defines the limit of the status regulation. By reducing the range you can create an artificial cutoff (the regulation range is lower than the available one).

• **Direction**: Vertical/Horizontal – position in space.

Other properties are set if required.

Trigger Button

Create a graphic item in Editor Workspace. Select **Type: Trigger Button** in Object Properties: General and indicate the item properties:

OBJECT PROPERTIES			0		50	100			
General	Progra	mming		States		0_			
Name		Item 7							
Left		339				50			
Тор		251				-			
Width		72					-		_
Height		66				100			
Active		True						on	
Visible		True						OII	
Specific						150			1
Туре		Trigger	Butte	on		130	-	-	-
Feedback		Channe	l			-			
Hit		Active T	Touch	ı		-			
Trigger Value 1		0				200_			
Trigger Value 2		100				-			

In the settings of **<u>Trigger Button</u>** indicate:

- **Feedback** way of reacting on events. **Channel** the item has to process data received from equipment and display them.
- **Trigger Value 1** and **Trigger Value 2** values Trigger Button switches at each pressing on it. Each time the item selects the value for sending which is opposite to the current one. Feedback channels are used for defining the current value.

Up/Down Button

Create a graphic item in Editor Workspace. Select **Type: Up/Down Button** in Object Properties: General and indicate the item properties:

OBJECT PROPERTIES		0 50	0 100	OBJECT PROPE	RTIES		0 450 500
General Progra	mming States			General	Programming	States	
Name	Item 9			Name	Item 8		
Left	142	50		Left	142		
Тор	234			Тор	83		
Width	72			Width	72		
Height	66	100		Height	66		
Active	True	-		Active	True		
Visible	True		+	Visible	True		
Specific		150		Specific			
Туре	Up/Down Button	150_		Туре	Up/Down E	Button	
Feedback	Momentary			Feedback	Momentar	/	
Hit	Active Touch			Hit	Active Tou	ch	
Up/Down Value	-10	200_		Up/Down Value	10		
Max/Min Value	0	-		Max/Min Value	100		

In the settings of <u>Up/Down Button</u> indicate:

• Feedback - way of reacting on events. Channel - the item has to process data received from equipment and display them.

- **Up/Down Value** the step of increment/decrement at each pressing ("-10" / "10" decrement and increment)
- **Min/Max Value** limits which cannot be exceeded. For decrementing the lowest limit is indicated, for incrementing the highest limit (for example, "0" for decrementing "-10" and "100" for incrementing "10").

Assigning commands to graphic items (through the example of Level)

Assign the command to the set up items (Level, Trigger Button or Up/Down Buttons) – it is performed similarly in all cases.

Select the **"Send Token"** tab in the dialog window. It is ALWAYS used with Levels, Trigger Buttons and Up/Down Buttons. It allows you to send the value corresponding the current position of the Level slider to the device:



Assign the feedback channel (Feedback) to the item with the **"In Value**" tag to display the current status of the controlled device – to affect the item state (in this case the slider position):



It is REQUIRED to assign feedback channels to Trigger Buttons and Up/Down Buttons. Otherwise the items will not work! It is not required to assign feedback channels to Level but you will need them for start initialization and displaying the actual status.

<u>↑ Back</u>

"Recall Scene (Device/Group)" - Recalling Scenes

Use the "Recall Scene Device / Group" command to recall scenes programmed for a device or group of devices. The command for recalling scenes can be directed to loads only (dimmers, relay modules, etc.):

← ➡ Recall Scene Device		← → Channel 1	
PROPERTIES		PROPERTIES	
Name	Recall Scene Device		
Command	Recall Scene Device	Name	Channel 1
Cluster	1	Command	Recall Scene Group
Router	1	Group	1
Subnet	1	CL	0
Device	10	Block	1
CL	1	Fade Time	100
Block	1		
Fade Time	100		

Commands - commands to devices and groups of devices

- Command: Recall Scene Device recalling the device scene
- Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255) the device address (@ address)

or Group (1..16383) – the address of a group of devices in the Helvar system

- **CL** Constant Light (1 = On, 0 = Off)
- Block (1..8) the block number. Scene 1.2 block 1, scene 2 (see Helvar Designer).
- Fade Time (ms) (0..6553.5s) speed of changing the device status from the current to the preset one after receiving the command of setting up the status.

The number of the scene you need to recall is selected as the "Value" property when dragging the command to the graphic item.

Graphic items used for recalling scenes:

When the command for controlling scenes is set up it is required to assign it to graphic items of the project. Each item can recall its own scene. In order to do that the following graphic items are used:

• **Buttons** – each item can store the number of the scene it has to activate. When pressing on Button the stored value is sent to the Helvar system.

<u>↑ Back</u>

Recalling scenes by Button

Create **Button** with 1 or 2 states. With the help of Button you can recall scenes in the Helvar system by number (1, 2, 3, ...).

Drag the command from the device tree to Button and select the **Send Number** tag in the dialog window – send the value:

 ■ Helvar Net ■ Driver Toke ■ Commands → Dire → Rec ■ Feedback 	(TCP) ns ct Level Device all Scene Device	Helvar Net (TCP) Driver Tokens Commands → Direct Level Devi Recall Scene Dev E Feedback	ice vice
Send String ← Que	ery Load Level	Send Command	
Send Number Send Token Send Binary Data		Action: Send Number Event for Action Press	Value
Name	Recall Scene Device	Release 1	Value
Cluster	1		Value
Router	1		
Subnet	1		Value
	1		
Block	1	Ok	Cance

Select the interface event and value (Value - the scene number), which should be sent to a device or a group of devices in the Helvar system:

- Press the command is sent when pressing on Button
- Release the command is sent when releasing on Button

The assigned command will be displayed in the **Programming** tab of the **Object Properties** window. If it is necessary the command can be transferred from the Press event to Release by dragging it by the text field.

<u>↑ Back</u>

"Direct Proportion (Device/Group)" - Setting up Proportions

When using "Direct Proportion" the value which will be set up is calculated as the difference between the last taken value (set up by the scene or directly) and its maximum value.

When setting up the proportion positive value it is calculated as the difference between the current value and the maximum level (100%).

For example, if the last recalled scene set up the value for 44% and you activate the "Direct Proportion (Device)" command for proportional increment of the level by 50%, the value will be set for 72%. It is calculated according to the following formula:

44% + (100 - 44)*50% = 72%

When setting up the proportion negative value it will be calculated as the difference between the current value and 0%:

For example, if the last recalled scene set up the value for 44% and you activate the "Direct Proportion (Device)" command for proportional decrement of the level by 50%, the value will be set for 22% (i.e. the value which equals to 50% from 44%):

(44%/100)*50% = 22%

The command of controlling proportions can be used for gradual increment or decrement of the current level value. The value range of the function of the directly proportional value change is from -100 to 100%.

The following commands of setting up proportions also will use the level value set up by scenes or directly (not the last one set up by proportions).

<u>↑ Back</u>

Setting up proportions by Button

Create **Button** with 1 or 2 states. With the help of Button you can send any value, in our case it is a proportion (1, 5, 10, -10,...).

Drag the command from the device tree to Button and select the **Send Number** tag in the dialog window – send the value:



Commands - commands to devices and groups of devices

- Command: Direct Proportion (Device/Group) setting up proportions
- Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255) the device address (@ address) or Group (1..16383) the address of a group of devices in the Helvar system
- Fade Time (ms) speed of changing the device status from the current to the preset one after receiving the command

Select the interface event and value (Value – the proportion value, -100..100), which should be sent to a device or a group of devices in the Helvar system:

- Press the command is sent when pressing on Button
- Release the command is sent when releasing on Button

The assigned command will be displayed in the **Programming** tab of the **Object Properties** window. If it is necessary the command can be transferred from the Press event to Release by dragging it by the text field.

<u>↑ Back</u>

"Modify Proportion (Device/Group)" - Modifying Proportions

The "Modify Proportion" function uses the same formula as the function of setting up proportions. But the proportion is calculated from the value which was set up by the previous "Direct Proportion" command and not by the value set up by scenes or directly. For example, let us take the result of applying the "Direct Proportion" command described in the previous section – 72%. When sending the command «modify the proportion by 5%», the level will change from 72% to 75% according to the following formula:

44% + (100 - 44)*(50% + 5%) = 74,8% = 75% (see the initial calculation in the previous section)

According to the formula when sending the negative value the indicated value is deducted from the value set up by the direct proportion. The command «modify the proportion by -5%» will change the variable value from 72% to 69% according to the following formula:

44% + (100 - 44)*(50% - 5%) = 69,2% = 69% (see the initial calculation in the previous section)

This way can be used for correcting values set up by the "Direct Proportion" command.

The value range of the function modifying proportions is from -100 to 100%.

<u>↑ Back</u>

Modifying proportions by Button

Create **Button** with 1 or 2 states. With the help of Button you can send any value, in our case it is a modification value in the percentage terms from maximum (1, 5, 10, -10,...).

Drag the command from the device tree to Button and select the **Send Number** tag in the dialog window – send the value:



Commands - commands to devices and groups of devices

- Command: Modify Proportion (Device/Group modifying proportions
- Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255) the device address (@ address) or Group (1..16383) the address of a group of devices in the Helvar system
- Fade Time (ms) speed of changing the device status from the current to the preset one after

receiving the command

Select the interface event and value (Value – the modification value, -100..100), which should be sent to a device or a group of devices in the Helvar system:

- Press the command is sent when pressing on Button
- Release the command is sent when releasing on Button

The assigned command will be displayed in the **Programming** tab of the **Object Properties** window. If it is necessary the command can be transferred from the Press event to Release by dragging it by the text field.

<u>↑ Back</u>

Requests and Emergency Tests

The requests for the device status in the Helvar system are formed in the **Feedbacks** tab of the project device tree.

For periodical request about the state it is required to create the feedback channel which is activated on timer with a certain interval.

When working by the protocol which supports auto-notification about changing the status in the system. The feedback channel is created without timer.

Request:	Description:
General Query Commands - gene	ral requests:
Query Clusters	all identifiers of items (Cluster Member) in the cluster
Query Routers	all identifiers in the indicated cluster
LSIB - Last Scene In Block	the last activated scene of the indicated block
Query Device Type	the type of the requested device. 1 - DALI, 2 - Digidim, 4 - SDIM, 8 - DMX
Query Description (Device/Group)	device/group description
Device State Query Commands -	the device state
Query Device State	device flags (parameters) - list
Query Device Is Disabled	disabling the device
Query Lamp Failure	lamp failure
Query Device Is Missing	missing the device
Query Device Is Faulty	device failure
Query Emergency Battery Failure	failure of the emergency battery

Measurement / Input / Level Query Commands - requests about changes:

Query Measurement	changing analog parameter, for example, light (Analogue Input Unit)
Query Inputs	state of the digital input

the device status
nands - power consumption:
power consumption of the device
power consumption of all devices in the group
ls - emergency tests:
time of the emergency test
status of the emergency test. Pass - 0, Lamp Failure - 1, Battery Failure - 2, Faulty - 4, Failure - 8, Test Pending - 16, Unknown - 32
duration of the emergency test
duration of the emergency state
charge of the emergency battery
total working time of the emergency battery
total working time of the lamp from any power source

System Query Commands - system tests:

Query Time, Longitude, Latitude, Time Zone, Daylight Saving Time, Software Version, HelvarNet Version,

Emergency Test Control Commands:

Commands for sending to DALI interfaces only. There will be no response from non-emergency devices:

Command:	Description:
Emergency Function Test (Device/Group)	request about emergency deice functions
Emergency Duration Test (Device/Group)	request about duration of the emergency state
Stop Emergency Tests (Device/Group)	stop all emergency tests

Examples of requests on timer:

"Query Load Level" - Requests about the Device State

Query Load Level – the request created in the project device tree as a feedback channel. It requests the status of the controlled device (used for separate devices only) and sends it to the interface. For example, it can send the state of relays and dimmer brightness value.

Value	r Net (TCP) 7 Tokens Dands Dack 9 Level 9 Query Device State - Disabled 9 Query Device State - Lamp Failure
Name Command Cluster Router Subnet Device Use Timer Timer	Level Query Load Level 1 1 1 10 yes 1000

Feedbacks - feedback channels for requesting and displaying the status of devices

- Command: Query Load Level requesting the device status
- Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255) the device address (@ address) or Group (1..16383) the address of a group of devices in the Helvar system
- **Use Timer:** Yes the request about the device status on timer (HelvarNet does not send the status without requests). If the timer is on, the device status will not be received.
- **Timer, ms:** XXXX frequency of requesting the device status in ms (how often it is required to update information about the device state in the project). The less often is the update, the less is the load on the system.

To display the current status of the controlled device assign the feedback channel (Feedback) to the item with the **"In Value**" tag – affect the item state (in this case - on the slider position).

<u>↑ Back</u>

"Query Device State" - Requesting Device Parameters (Flags)

Each device in the Helvar system of controlling lighting can send information about a number of its parameters (flags) by special requests. This function ca be used when monitoring the state of the lighting system.

To display device flags create the feedback channel in which settings it is required to indicate the device address and frequency of sending requests to the flag. The channel is assigned to **Button** which will display the flag status (0 – not active, 1 - active):

Disabled	Feedback Query Query Query	Load Level Device State - Disabled Device State - Lamp Failure
In Value	PROPERTIES	
In Text	Name	Query Device State - Di
More	Command	Query Device State
Lamp	Command Property	Disabled
	Cluster	1
	Router	1
	Subnet	1
	Device	10
	Use Timer	yes
	Timer	5000

 ${\bf Feedbacks}$ – feedback channels for displaying the device status

- Command: Query Device State requesting and displaying the device parameters (flags)
- Command Property device flag you need to display
- Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255) the device address (@ address) or Group (1..16383) the address of a group of devices in the Helvar system
- **Use Timer:** Yes the request about the device status on timer (HelvarNet does not send the status without requests). If the timer is on, the device status will not be received.
- **Timer, ms:** XXXX frequency of requesting the device status in ms (how often it is required to update information about the device state in the project). The less often is the update, the less is the load on the system.

Command Property	Description
Disabled	Device or subdevice has been disabled, usually an IR subdevice or a DMX channel
Lamp Failure	Unspecified lamp problem
Missing	The device previously existed but is not currently present
Faulty	Ran out of addresses (DALI subnet) / unknown Digidim control device / DALI load that keeps responding with multi-replies
Refreshing	DALI subnet, DALI load or Digidim control device is being discovered
Resting	Load is intentionally off whilst the control gear is being powered by the emergency supply
Reserved	
In Emergency	No mains power is being supplied
In Prolong	Mains has been restored but device is still using the emergency supply
FT In Progress	The Functional Test is in progress (brief test where the control gear is being powered by the emergency supply)
DT In Progress	The Duration Test is in progress. This test involves operating the control gear using the battery until the battery is completely discharged. The duration that the control gear was operational for is recorded, and then the battery recharges itself from the mains supply

List of flags for "Query Device State":

DT Pending	The Duration Test has been requested but has not yet commenced. The test can be delayed if the battery is not fully charged
FT Pending	The Functional Test has been requested but has not yet commenced. The test can be delayed if there is not enough charge in the battery
Battery Fail	Battery has failed
In Hi Bit	Prevents an emergency fitting from going into emergency mode
FT Requested	Emergency Function Test has been requested
DT Requested	Emergency Duration Test has been requested
Unknown	Initial state of an emergency fitting
Over Temperature	Load is over temperature/heating
Over Current	Too much current is being drawn by the load
Comms Error	Communications error
Severe Error	Indicates that a load is either over temperature or drawing too much current, or both
Bad Reply	Indicates that a reply to a query was malformed
Device Mismatch	The actual load type does not match the expected type