

Button	Sending fixed values; displaying data received from the controller
Level	Sending values from the preset range by the slider; displaying the current value by the position of the slider
Trigger Button	Switching between two fixed values indicated at the item setting
Up/Down Button	Incrementing/decrementing the current value by the preset value in the preset range. The range and the step of increment/decrement are set at the item setting.
Multistate Button	Sending fixed values and receiving data accompanied by animation
Multistate Level	Sending and receiving values in the preset range where each value or group of values has its own image
Edit Box	Inputting a string of data to be sent to the bus
Joystick	Controlling RGB with the help of ColorPicker