- C o n
- t

A license for i2 Control V2.2 is an \*.irl file which is uploaded i2 Control V2.2 via the <u>iRidium</u> <u>Transfer</u> application. The license file is uploaded on the control panel only with an iRidium project (\*.ir) – the visualization interface. On the control panel the license file enables connection to the equipment set up in the project.

# S

f

A license can be assigned to  $\underline{HWID}$  – the control panel identifier. Such license is called "Device License" and it can work only on this control panel.

# **† ! Tabout deletion of i2 Control V2.2**

Remember that i2 Control V2.2 for iOS ( iPad/iPhone/iPod touch) will change HWID if you delete the application and then install it again! Install one more application of the same developer (iRidium mobile) on your iOS device (for example, i2 Control and i2 Control V2.2 for HWID not to change at deletion of one of the applications.

A license can be assigned to <u>Serial number</u> -the serial number of one of the controllers of your installation: AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar. Such license is called "Site License" and it can be uploaded on any control panel as it is not related to HWIDs (panel identifiers). Thus, you can connect any panel to the licensed controller. Do not forget that Site licensing is supported only by a limited list of controllers and systems: AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar.

# \_\_\_L

\_\_\_\_\_i If a control panel or controller are broken and have to be substituted by a new one, you can transfer your license to the new device for free in your <u>MY ACCOUNT</u> section on the iRidium mobile web site.

#### \_\_\_\_\_S To buy a license, you can use an online form or request an invoice. After the payment you will receive an activation key with which you will be able to <u>activate</u> the license – to assign it to your MY ACCOUNT section and HWID (or Serial Number). When the license is assigned to the control panel or controller, it can be downloaded from the web site as an \*.irl file and upload it on your control panel via <u>iRidium Transfer</u>.

# Types of iRidium Licenses

iRidium presents several types of licensing:

\_\_\_\_i \_\_\_\_g \_\_\_\_i \_\_\_\_c \_\_\_\_e \_\_\_\_n

v

\_\_\_\_n \_\_\_\_s \_\_\_\_e

S

# Types of iRidium Licenses

# Device License

one control panel any controller (see Products)

# Site License

✓ any number of control panels

one controller \*

<b>Types of iRidium licenses</b> for AV & Custom Systems, AMX, Clipsal, Crestron, Domintell, HDL-BUS Pro, Helvar, KNX, KNX IP BAOS, Modbus, EPSNET systems								
License	Supported equipment:	Number of supported control panels:	2-way control of Audio- Video:*	Support of <u>iRidium</u> <u>DDK</u> (Drivers API):	Required equipment:			
Device License	One of the systems + Audio-Video	1	×	×	×			
Device License Pro	One of the systems + Audio-Video	1	*	*	×			
Site License	One of the systems + Audio-Video	∞***	×	×	Controller for licensing**			
Site License Pro	One of the systems + Audio-Video	<b>∞</b> ***	*	*	Controller for licensing**			

\* 2-way control of AV equipment is sending commands and receiving feedback. If there is no possibility of 2-way control, then you can only send commands but you cannot get feedback from AV equipment.

\*\* Site licensing supports only the systems where there are on the following controllers: AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar

\*\*\* the number of connected panels can be limited by the controller characteristics. See more information in the instructions for your type of equipment

<b>Types of iRidium licenses for several systems in one project</b> when a license has to support several solutions (for example, AMX + Modbus + AV or other combinations)										
License	Supported equipment:	Number of supported control panels:	2-way control of Audio- Video:*	Support of iRidium DDK (Drivers API):	Required equipment:					
FULL Device License Pro	All systems (besides HDL- BUS Pro) + Audio-Video	1	*	*	×					
FULL Device License Pro & HDL-BUS Pro	All systems+ Audio-Video	1	*	*	×					
FULL Site License Pro	All systems (besides HDL- BUS Pro) + Audio-Video	∞***	*	~	Controller for licensing**					
FULL Site License Pro & HDL	All systems+ Audio-Video	∞***	*	*	Controller for licensing**					

\* 2-way control of AV equipment is sending commands and receiving feedback. If there is no possibility of 2-way control, then you can only send commands but you cannot get feedback from AV equipment.

\*\* Site licensing supports only the systems where there are on the following controllers: AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar

\*\*\* the number of connected panels can be limited by the controller characteristics. See more information in the instructions for your type of equipment

Use with any iRidium license the following functions which will work with any acquired license								
Applications for iOS, Android, Windows, OS X	1-way integration with Global Cache and other Audio-Video	iRidium Script API + <u>iRidium DDK</u> in Pro licenses						
IP cameras (without limitations)	SIP client (without limitations)	Password protection of projects (4 levels)						
Unlimited number of commands for the licensed solution	Unlimited number of pages and graphic items, GUI animation	Multi-design: several GUIs on one control panel						

# **Description of license types:**

**Device License** - a license for controlling of the supported systems (AMX, KNX, Crestron, etc.) from one control panel. It supports the following functions:

- 1-way communication with AV equipment (without feedback from AV)
- control of any supported controller from 1 device
- possibility to combine 2 Device Licenses for controlling different automation systems (for example, AMX + Crestron)
- no support of iRidium Script modules
- no possibility to use drivers and scripts for AV (see <u>iRidium DDK</u>)

**Device License Pro** – in addition to the basic functions it enables 2-way communication with AV equipment, supports <u>iRidium Script modules</u>, enables writing of drivers and scripts for AV equipment (<u>iRidium DDK</u>).

**Full Device License Pro** – it is used for controlling several systems (AMX, KNX, Crestron, etc.) from one control panel. It supports all the system if the licensed controller Online.

**Site License** - a license for controlling one of the supported systems (AMX, KNX, Crestron, etc.) from several control panels:

- it licenses any number of panels for connection to 1 controller (AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar)
- the number of connected panels can be limited by the controller characteristics. See more information in the instructions for your type of equipment
- connection to other controllers of the same type is possible if the licensed controller is online and is set up in the visualization project
- it enables control of AV equipment (without feedback from AV) until there is a connection with the licensed controller
- no support of iRidium Script modules
- no possibility to use drivers and scripts for AV (see <u>iRidium DDK</u>)

**Site License Pro** – – in addition to the basic functions it enables 2-way communication with AV equipment, supports <u>iRidium Script modules</u>, enables writing of drivers and scripts for AV equipment (<u>iRidium DDK</u>).

**Full Site License Pro** – it is used for controlling several systems (AMX, KNX, Crestron, etc.) from any control panel. It supports all systems besides HDL-BUS Pro (for each there is a separate Full Site license). It enables control other equipment until there is a connection with the licensed controller.

## Examples of choosing suitable iRidium licenses for your projects

Example 1:

a. You need to control a TV and a DVD player via IR through Global Cache. At that you need to be able to read data from sensors connected to Global Cache by 2 iPads.b. You also need to control Sonos/XBMC/Kramer/etc.The best choice is "Device License Pro" for AV & Custom Systems (2 licenses).

#### Example 2:

You need to control Crestron from 2 iPads. The best choice is "Device License" for Crestron (2 licenses).

#### Example 3:

You need to control KNX and Sonos from 1 Android smart phone. The best choice is "Device license Pro" for KNX (1 license)

#### **Example 4:**

You need to control KNX from 2 Android OS based smart phones, 2 iPhones and 1 PC (5 devices in total).

The most suitable license is:

a. "Site License" for BAOS (1 license). You will need a KNX IP BAOS router and setting up of datapoints in ETS for it.

b. "Site License" for KNX (1 license). You will need a KNX IP BAOS router. You don't need to set up datapoints (but you will need to set up of the multiclient function for BAOS).

 $\ast$  the difference between the ways of connection to KNX is described in the section iRidium for KNX

#### Example 5:

You need to control KNX, Modbus controller and a NEC projector through Global Cache from 1-2 control panels.

The best choice is "Full Device License Pro" for KNX (1-2 licenses).

#### <u>↑ Back</u>

# **Receiving Licenses**

<u>iRidium products</u> are licensed with the help of *activation keys* which you can get at iRidium Mobile web site:

Buy licenses on the iRidium mobile web site you are required to go through Full registration on the iRidium mobile web site as a company or freelancer engaged in the automation field to be able to buy iRidium products.

Buy licenses from iRidium distributors to buy licenses contact the official iRidium distributor in your country. See the list of distributors <u>here</u>

# **Activation of iRidium Licenses**

A license for i2 Control V2.2 is an \*.irl file which is uploaded i2 Control V2.2 via the <u>iRidium</u> <u>Transfer</u> application. The license file is uploaded on the control panel only with an iRidium project (\*.irpz) – the visualization interface. On the control panel the license file enables connection to the equipment set up in the project.

A license can be assigned to  $\underline{HWID}$  – the control panel identifier. Such license is called "Device License" and it can work only on this control panel.

#### [!] about deletion of i2 Control V2.2

Remember that i2 Control V2.2 for iOS ( iPad/iPhone/iPod touch) will change HWID if you delete the application and then install it again! Install one more application of the same developer (iRidium mobile) on your iOS device (for example, i2 Control and i2 Control V2.2 for HWID not to change at deletion of one of the applications.

A license can be assigned to <u>Serial number</u> -the serial number of one of the controllers of your installation: AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar. Such license is called "Site License" and it can be uploaded on any control panel as it is not related to HWIDs (panel identifiers). Thus, you can connect any panel to the licensed controller. Do not forget that Site licensing is supported only by a limited list of controllers and systems: AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar.

If a control panel or controller are broken and have to be substituted by a new one, you can transfer your license to the new device for free in your <u>MY ACCOUNT</u> section on the iRidium mobile web site.

To buy a license, you can use an online form or request an invoice. After the payment you will receive an activation key with which you will be able to <u>activate</u> the license – to assign it to your MY ACCOUNT section and HWID (or Serial Number). When the license is assigned to the control panel or controller, it can be downloaded from the web site as an \*.irl file and upload it on your control panel via <u>iRidium Transfer</u>.

### **Device License: activation and using**

#### See the instructions...

### 1. Authorize on the iRidium mobile web site, go to the <u>MY ACCOUNT</u> section.

To access the MY ACCOUNT section it is necessary to go through <u>registration</u> on the web site, after the registration you will be able to activate iRidium licenses.

# 2. Add your license activation key in the MY ACCOUNT section

MAIN P	RODUCTS DOWNLOAI	D SUPPORT	FORUM PART	NERS ACADEMY	ABOUT US		it 🍵 BUY
Buy	My Licenses My P	rofile Tria	al				
	Add folder		Add key 🖉				
Туре	License name	Drivers	Activation key	Purchase/activation	HWID/Serial	Download license file	Deactivate 🖉
Gen	eral					Edit folder	Delete folder
iridi	um.license-maker.com					Edit folder	Delete folder

You will receive the license activation key consisting of 160 symbols.

You need to add this key to the list of licenses (MY LICENSES) in your <u>MY ACCOUNT</u> section of the iRidium mobile web site to be able to activate the license.

Do not forget that licenses added in your MY ACCOUNT section are assigned to your account and you cannot transfer them to another account.

#### 3. Activate the Device license key for one of your panels (iOS/Windows/Android/OS X).

The license key can be activated in the list of licenses (MY LICENSES) where you added it. Press on the " **Activate**" button in the line with information about the key:

MAIN	PRODU	CTS DOWNLOA	D SUPPORT	FORUM PAR	TNERS ACADEMY	ABOUT US	BLOG MY ACCOL	INT 💮	BUY
Buy	My Lic	enses My F	Profile Tr	ial					
	Add	folder 🔘		Add key 🛛 🖉	)				
Ту	pe	License name	Drivers	Activation key	Purchase/activation date	HWID/Serial	Download license file	Deactivate	$\oslash$
( ) G	eneral						🖉 Edit folder	💓 Delete fo	lder
Tri	al	Trial 16.07.2013	ANIX AXICO, MODBUS TCP, MODBUS ASCII,	f8895f43e8 🕑	07/16/2013/ not active	Activate	( <u>+</u> )	Not supported	$\oslash$

Add HWID in the window – it is the identifier of your device (iOS/Windows/Android/OS X).

You can receive HWID</a> with the help of iRidium Transfer. Copy HWID in the window and press on the OK button:

Activate key	
HWID/Serial 0f2c589a2879c0fe1d58697d5d4c1911	
	Ok Close

## 4. Download the license file on your PC.

You can download the license file on your PC by pressing on the Download button in the line with information about the activated license:

MAIN PR	ODUCTS DOWNLOA	D SUPPORT	FORUM PART	INERS ACADEMY	ABOUT US B		NT 💮	T BUY
Buy M	y Licenses My F	Profile Tr	ial					
	Add folder 💿		Add key 🛛 🖉					
Туре	License name	Drivers	Activation key	Purchase/activation date	HWID/Serial	Download license file	Deactivate	$\bigcirc$
iridiu	m.license-maker.com					C Edit folder	🕱 Delete fo	older
Avangate	License 1	AMX, AXICO, MODBUS TCP, MODBUS ASCIL	15e5f0eec2 🕑	05/13/2010/ 05/13/2010	45e5781a08	٤	0/1 Deactivate	$\oslash$

Save the license file on your PC:

4			P.
License 3.irl	*	Show all downloads	×

#### \*5. Other actions with licenses (deactivation)

If you need to assign the activated license to another device (error at the activation, update of your control device or its replacement due to breaking), you can deactivate the license and go through the activation process again but use HWID of another device. The number of deactivations is **limited**. You can see the number of the deactivations you can use in the line of the license status (used/total):

MAIN PRO	DUCTS DOWNLOAD	D SUPPORT	FORUM PART	INERS ACADEMY	ABOUT US E	BLOG MY ACCOU	NT 🔒	BUY
Buy My	Licenses My P	rofile Tri	al					
A	dd folder 🔘		Add key 🛛 🖉					
Туре	License name	Drivers	Activation key	Purchase/activation date	HWID/Serial	Download license file	Deactivate	$\oslash$
iridium.	license-maker.com					C Edit folder	Delete fo	lder
Avangate	License 1	ANDC AXICO. MODBUS TCP. MODBUS ASCIL	15e5f0eec2 🕫	05/13/2010/ 05/13/2010	45e5781a08	٤	0/1 Deactivate	$\oslash$

With the help of the "Edit key" you can change the folder for storing the license and rename the license.

### 6. Use the license in Transfer

You need to add the license file downloaded on your PC to the <u>iRidium Transfer</u> application. In order to do that drag the file in the application window or press on the "Add license" button:



Now in the Panels tab you can select the license for the device with HWID it was activated for. You will not be able to select this Device license for a device with another HWID:



After that the license file will be uploaded on your control panel together with the iRidium project.

## 7. Add the license for Emulator in iRidium GUI Editor

You can license Emulator in iRidium GUI Editor to enable communication between your project and controlled equipment. In order to do that you need to activate the license key for HWID of your PC (it is marked as "Your PC" in Transfer).

The path to the license file is set up in the GUI Editor settings:

× 1	Ridium G	JI Edi	itor									
File	Project	Tool	sHelp View 🗄 🖹		2	😫 😫 🖉	10	Emula	tor 🧈 Sen	d To Panel		
	k 🚦	=	Language	•	1	Options					×	ì
<ul> <li>Pages Overview</li> </ul>	PROJEC	*	Options Certificates Default Panels Size	•	>	Emulator Client License Demo Mode: License Path:	Showi	ng D:\Lic	Scan enses\Wy_PO	File Operating	Default Cont	
Gallery						Client Fullscreen: Client Sound On: Show Log at Emul	ator star	2		СК	Cancel	

• *License Path* – it is the path to the license file for your PC (Windows), which enables work in the fully functional mode.

### Site License: activation and using

#### See the instructions...

#### 1. Authorize on the iRidium mobile web site, go to the <u>MY ACCOUNT</u> section.

To access the MY ACCOUNT section it is necessary to go through <u>registration</u> on the web site, after the registration you will be able to activate iRidium licenses.

#### 2. Add your license activation key in the MY ACCOUNT section

MAIN PROD	DUCTS DOWNLOAD	SUPPORT	FORUM PAR	TNERS ACADEMY	ABOUT US		NT 💮 BUY
Buy My I	Licenses My Pr	ofile Tri	al				
Ad	ld folder 🔘		Add key 🛛 🖉				
Туре	License name	Drivers	Activation key	Purchase/activation date	HWID/Serial	Download license file	Deactivate 🖉
General						🖉 Edit folder	Delete folder
iridium.l	icense-maker.com					C Edit folder	Delete folder

You will receive the license activation key consisting of 160 symbols. The license key can be assigned to one of the following controllers only: AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar.

You need to add this key to the list of licenses (MY LICENSES) in your <u>MY ACCOUNT</u> section of the iRidium mobile web site to be able to activate the license.

Do not forget that licenses added in your MY ACCOUNT section are assigned to your account and you cannot transfer them to another account.

#### 3. Activate the Site license key using the controller serial number.

The license key can be activated in the list of licenses (MY LICENSES) where you added it. Press on the "Activate" button in the line with information about the key:

MAIN PROD	UCTS DOWNLOAI	D SUPPORT	FORUM PAR	TNERS ACADEMY	ABOUT US	BLOG MY ACCOU	INT 🔶	BUY
Buy My I	icenses My P	rofile Tri	ial					
Ad	d folder 🔲		Add key 🛛 🖉	)				
Туре	License name	Drivers	Activation key	Purchase/activation date	HWID/Serial	Download license file	Deactivate	$\oslash$
General						🖉 Edit folder	🕱 Delete fo	older

You will see the window requesting the serial number of the controller you want to activate the license for. It should be the controller of the same type which is indicated in the information about the key.

**You can receive the serial number]** - the identifier of your controller (AMX, Crestron, KNX, KNX IP BAOS, HDL, Global Cache, Helvar) - with the help of the <u>iRidium Util</u> application.

Activate key			
HWID/Serial 00c501000033			
	Ok Close		

### 4. Download the license file on your PC.

You can download the license file on your PC by pressing on the Download button in the line with information about the activated license:

MAIN PRO	DUCTS DOWNLOA	D SUPPORT	FORUM PAR	TNERS ACADEMY	ABOUT US B		NT 💮 BUY
Buy My	Licenses My P	Profile Tr	ial				
A	dd folder 🔘		Add key 🛛 🖉	)			
Туре	License name	Drivers	Activation key	Purchase/activation date	HWID/Serial	Download license file	Deactivate 🖉
iridium.license-maker.com						Delete folder	
Avangate	License 1	ANDC AXICO. MODBUS TCP. MODBUS ASCIL	15e5f_0eec2 🕫	05/13/2010/ 05/13/2010	45e5781a08	*	0/1 Deactivate

Save the license file on your PC:

<			3
License 3.irl	*	Show all downloads	×

# \*5. Other actions with licenses (deactivation)

If you need to assign the activated license to another device (error at the activation, update of your control device or its replacement due to breaking), you need to contact iRidium mobile Support

Team and describe them your problem: <a href="mailto:support@iridiummobile.ru">support@iridiummobile.ru</a>

With the help of the "Edit key" you can change the folder for storing the license and rename the license.

#### 6. Use the license in Transfer

You need to add the license file downloaded on your PC to the <u>iRidium Transfer</u> application. In order to do that drag the file in the application window or press on the "Add license" button:

🐼 iRidium Tensfer - [Projects]				
Panels 2 General 7 Projects	Name	Туре	Serial	Used devices
	AMX Site License Pro	Site	210506x40b0129	АМХ
	Trial 29.05.2013		eb55	
<ul> <li>General</li> <li>Licences</li> </ul>	Trial 06 06 2013(1)	Trial (Valid to 24.09.)	Devic	Libraries > Documents > License
🔍 General	110100.00.2013(1)	1101 (1010 CO 21.05.	Organize	<ul> <li>Share with           Burn New for     </li> </ul>
	BAOS 772	Site	00c5	
	Device Lic	Device	01b2	restron_Site.irl ype: IRL File
			L if	Pad Air.irl ype: IRL File
[01.09.2014 18:12:55:391] iRidium Tra	insfer			hone Scirl

Now in the Panels tab you can select the license for ANY device in Transfer. It can be uploaded on ANY control panel (iOS/Windows/Android/OS X) together with the iRidium project. Site license enables any control device to connect to the licensed controller:

😨 iRidium Transfer - [Panels]					
- 19 11+ m		Name	HWID	Licence	Project
\$\$ U.U.D	😏 🚥	HP (Your PC)	0f2c589a2879c0f	•	Project 2 🗸
General				General	
<ul> <li>&gt; Projects</li> <li></li></ul>				BAOS2_ultimate License	

After that the license file will be uploaded on your control panel together with the iRidium project.



#### See the instructions...

Trial License is similar to **Full Device License Pro**. Please follow the instructions for Device License when activating and using this license type.

# **Several Device Licenses on One Device**

If you want to control several automation systems (for example, HDL-BUS Pro and KNX, Crestron and Modbus) at a time, you can select iRidium Full which supports all iRidium drivers. Or you can get several separate Device licenses and create one common license file for the control panel.

Merge of license keys is performed automatically when their <u>activation</u> for one control panel (one <u>HWID</u>). You need to select two licenses and add the license keys to your MY ACCOUNT section. Then copy the panel HWID and activate both keys using the same HWID. After you activate the second key, download the license file – it will support drivers included in both keys.

It can be used when:

- you need to add new drivers to the license key you have
- you need "Pro" functions of the license: then you can buy a license for "AV & Custom Systems Pro" as an addition to the key you have
- when separate Device licenses is cheaper for you than iRidium Full Device license

You cannot use it:

• with Site or Site Pro. Merge of Site licenses is impossible!

You can check the license file for having drivers from both keys by adding it in Transfer:



<u>↑ Back</u>